

Preparing the USB stick

- Download the updated ZIP file from Service-PartnerNet (<https://partner.bora.com>).
- Unzip the ZIP file.
- The unzipped updated data must be loaded onto a FAT 32 formatted USB stick.



- i** Always use the latest update files. The files must not be modified.
- i** When a link with the USB stick is established, the extractor automatically detects which cooktops are connected and updates them with the appropriate update file.

Performing a software update

- i** Only fully functional cooktops can be updated. Ensure that it functions properly.




Fig. 1 Inserting the USB stick

- Insert the USB stick into the slot on the cooktop extractor.




Fig. 2 Activating the system

- Activate the whole system using any control knob.




Fig. 3 Accessing the configuration menu

- Press the fan knob until the second acoustic signal is heard.
- Turn the knob ring clockwise to menu item "Cb".

- i** The "Cb" is shown at 100% brightness when the USB stick is detected by the appliance.




Fig. 4 Starting a software update

- Tap "Cb" to start the update.
- Update time: approx. 1-2 minutes.
- Display on control knob: LAr - in the case of a whole system update, L-r if only the cooktops are being updated.

- The characters will then flash one after the other:
 - L flashing: left cooktop upgrade in progress.
 - R flashing: cooktop extractor upgrade in progress.
 - r flashing: right cooktop upgrade in progress.
- If the software update has been installed successfully, an acoustic signal will be heard and the system will display "FUE" (no error has occurred).
- If an error occurs during the update, "FUE" is displayed.
- ▶ Acknowledge this by tapping the display.

Final check

Perform data export




Fig. 5 Perform data export

- i** Wait at least 2 minutes between software update and data export.
- ▶ Press the fan knob until the second acoustic signal is heard.
- ▶ Turn the knob ring clockwise to menu item "C c".
- ▶ Tap "C c" to start the data export.
- During data export, "dE" is displayed on the control knob.
- When the data export is complete, "dE0" is displayed on the control knob.
- ▶ Remove the USB stick from the appliance

Checking the software version

- i** Wait at least 2 minutes between software update and checking the software version.




Fig. 6 Checking the software version

- ▶ Press the fan knob until the second acoustic signal is heard.
- ▶ Turn the knob ring clockwise to menu item "C c".
- ▶ Tap on "C c" to display the current software version.
- ▶ Turn the knob ring to display the software version of the corresponding component (cooktop on the left, cooktop extractor or cooktop on the right).
- The software version displayed must match the updated version.

Troubleshooting

- If the "b" in menu item "C b" is not lit up, the system was unable to detect a USB stick.
- ▶ Remove the stick for 5 seconds and then reinsert it.
- or
- ▶ Leave the stick in the appliance and switch off the power supply for 1 minute.

Other troubleshooting methods:

- ▶ The file names of the update files must not be modified (especially ".upd").
- ▶ Call up configuration menu "C b" and then insert the USB stick.