

**INT BORA Professional 3.0**
**Kurzanleitung Funktionen und Bedienung**

Quick guide functions and operation

Guía rápida funciones y uso

Guide rapide fonctions et utilisation

Guida rapida funzioni e uso

Snelgids functies en bediening

PKA3/PKA3AB, PKAS3/PKAS3AB

**Abzugsautomatik**




Automatic extractor function

Mecanismo automático de extracción

Aspiration automatique

Sistema di aspirazione automatica

Automatische afzuiging


**aktivieren** / activate / activar / activer / attivare / activeren

**deaktivieren** / deactivate / desactivar / désactiver / disattivare / deactiveren


PKA3/PKA3AB, PKAS3/PKAS3AB

**Kurzzeit-Timer (Eieruhr)**





Short-time timer (egg timer)

Alarma de tiempo corto / temporizador de cocina

Minuteur d'alarme

Contaminuti breve


Timer voor korte tijdsspanne / eierwekker


**aktivieren** / activate / activar / activer / attivare / activeren

**Zeit einstellen** / set time / ajustar el tiempo / régler la minuterie / impostazione tempo / Tijd instellen



PKA3/PKA3AB, PKAS3/PKAS3AB, PKFI3/PKFI3AB, PKI3, PKIW3, PKC3, PKCB3, PKCH3, PKG3, PKT3

**Kindersicherung**


Childproofing feature  
 Dispositivo de seguridad para niños  
 Sécurité enfant  
 Protezione bambini  
 Kinderbeveiliging




**aktivieren** / activate / activar / activer / attivare / activeren



**für einen Kochvorgang deaktivieren** / deactivating for a cooking session / desactivar para un proceso de cocción / désactivez pour un processus de cuisson / disattivazione per un processo di cottura / voor een kookproces deactiveren



**deaktivieren** / deactivate / desactivar / désactiver / disattivare / deactiveren




PKA3/PKA3AB, PKAS3/PKAS3AB, PKFI3/PKFI3AB, PKI3, PKIW3, PKC3, PKCB3, PKCH3, PKG3, PKT3


**Pausefunktion**

Pause function  
 Función de pausa  
 Fonction de pause  
 Funzione pausa  
 Pauzefunctie

**aktivieren** / activate / activar / activer / attivare / activeren




**deaktivieren** / deactivate / desactivar / désactiver / disattivare / deactiveren




PKFI3/PKFI3AB, PKI3, PKIW3, PKC3, PKCB3, PKCH3, PKG3

**Variable Warmhaltefunktion**


Variable heat retention function  
 Función de mantenimiento de la temperatura variable  
 Fonction de maintien au chaud variable  
 Funzione mantenimento calore variabile  
 Variabele warmhoudfunctie




**aktivieren/activate/activar/activer/attivare/activeren**  
 PKFI3/PKFI3AB, PKI3, PKIW3, PKG3



**aktivieren/activate/activar/activer/attivare/activeren**  
 PKC3, PKCB3, PKCH3




**deaktivieren/deactivate/desactivar/désactiver/disattivare/deactiveren**




PKFI3/PKFI3AB, PKI3, PKIW3, PKC3, PKCB3, PKCH3, PKG3

**Timer-Funktion (Abschaltautomatik)**


Timer function (automatic cut-off)  
 Función de temporizador/desconexión automática  
 Fonction de minuteur de cuisson/arrêt automatique  
 Funzione timer/sistema di spegnimento automatico  
 Timerfunctie/automatische uitschakeling



**aktivieren/activate/activar/activer/attivare/activeren**




**Zeit einstellen / set time / ajustar el tiempo / régler la minuterie / impostazione tempo / Tijd instellen**




PKFI3/PKFI3AB, PKI3, PKIW3, PKC3, PKCB3, PKCH3, PKG3

**Ankochautomatik**

Automatic heat up function  
 Sistema automático de precalentamiento  
 Cuisson automatique  
 Avvio di cottura automatico  
 Automatische aankookfunctie




aktivieren/activate/activar/activer/attivare/activeren




PKC3, PKCB3, PKCH3

**Heizkreis-Zuschaltung – 2-Kreis, 3-Kreis, Bräter**

Additional ring switching – 2-ring, 3-ring, roaster  
 Conexión de círculos calentadores – 2 círculos, 3 círculos, asador  
 Activation de feux – 2 feux, 3 feux, sauteuse  
 Attivazione circuito di riscaldamento – 2 circuiti, 3 circuiti, bisticchiera  
 Bijschakeling van verwarmingsringen – 2 ringen, 3 ringen, braadslee



aktivieren/activate/activar/activer/attivare/activeren




PKFI3/PKFI3AB, PKT3

**Brückenfunktion**

Bridging function  
 Función puente  
 Fonction de pont  
 Funzione bridge attiva  
 Brugfunctie

aktivieren/activate/activar/activer/attivare/activeren



deaktivieren/deactivate/desactivar/désactiver/disattivare/deactiveren

